

## Flaring Tools

Part #	Description
R222402	1/8"- 3/4" Eccentric Flaring Tool, 45° Flare
4930000	1/8"- 3/4" Flaring Tool, 45° Flare

## Maxi Tube Bender

Part #	Capacity	Wt.
R23022	Maxibender Kit for Bending Soft Copper Includes Formers for: 3/8", 1/2", 5/8", 3/4", 7/8" Bends up to 90° In a Metal Case	10 Lbs.

## Tee-Extractors

Part #	Description
22124	Extractor Set: Unidrill 42, Cam Pincer Pliers, Ratchet, 4 Heads: 1/2", 5/8", 7/8", 1-1/8"
22081	Ratchet Handle to 1 3/8"
21575	Unidrill 42 3/8" - 1 5/8"
22080	Extractor Cam Pincer

## Tube Expander

Part #	Description	Max. Wall Thickness
12324	Expander Set with Expander Tool, Deburring Tool, 4 Heads: 1/2", 5/8", 7/8", 1-1/8"	
12000	Expander Tool only	
11008	5/16" Expander Head	.04"cu
11052	3/8" Expander Head	.04"
11053	1/2" Expander Head	.05"
11054	5/8" Expander Head	.05"
11055	3/4" Expander Head	.05"
11056	7/8" Expander Head	.05"
11058	1-1/8" Expander Head	.065"
11035	1-3/8" Expander Head	.065"
11062	1-5/8" Expander Head	.065"


## Hydrostatic Test Pump

Part #	Description
RP50	Hydrostatic Test Pump: 0-60 bar, 1 bar steps: 0-860 psi, 20 psi steps. Tank Capacity:3.2 gal. Suction:1.5oz per stroke



### Tee-Extractor Features

- No Pipe Cutting
- For Precision Joints
- 3/8" - 2 1/8" Capacity
- Eliminates Extra Fittings
- Forged Hooks, Tempered



### Tube Expander Features

- Saves on Joints
- Easy to use
- 50% Less Soldering
- Saves on fittings

